



ハロゲンソケット

口金 EZ10/E11


品番	TS-603-EZ10 TS-603S-EZ10 (TS-600(S)-EZ10 代替品)		
	 <p>TS-603-EZ10 TS-603S-EZ10</p> <p>EZ10 下面取付</p>		
定格	7A30V	入数	—
外郭	磁器		




品番	TS-604-EZ10 TS-604S-EZ10 (TS-601(S)-EZ10 代替品)		
	 <p>TS-604-EZ10 TS-604S-EZ10</p> <p>EZ10 上面取付</p>		
定格	7A30V	入数	—
外郭	磁器		




品番	TS-605S-EZ10 (TS-602S-EZ10 代替品)		
	 <p>EZ10 上面前部取付</p>		
定格	7A50V	入数	—
外郭	セラミック		




品番	TS-620-E11 TS-620S-E11 (旧品番: E-11F,FS)		
	 <p>E11 下面取付</p>		
定格	5A125V	入数	—
外郭	セラミック		




品番	TS-621-E11 TS-621S-E11 (旧品番: E-11G,GS)		
	 <p>E11 上面取付</p>		
定格	5A125V	入数	—
外郭	セラミック		




品番	TS-628-E11 TS-628S-E11		
	 <p>E11 下面取付</p>		
定格	7A300V	入数	—
外郭	磁器		



品番	TS-624-E11 TS-624S-E11		
	 <p>E11 上面取付</p>		
定格	7A300V	入数	—
外郭	磁器		




品番	TS-625S-E11 (TS-622S-E11 代替品)		
	 <p>E11 上面前部取付</p>		
定格	7A125V	入数	—
外郭	セラミック		



ハロゲンソケット

口金 G4/G6.35

品番	TS-650-G4		
	(旧品番 : C-14A)		
 <p>G4 小型ソケット</p>			
定格	5A30V	入数	—
外郭	セラミック		



品番	TS-654-G6.35		
	(旧品番 : C-17N)		
 <p>G6.35 高ワット小型ピン式</p>			
定格	7A30V	入数	—
外郭	セラミック		

