



ランプソケット
口金 E10/E12

ソケット品番表示について (例) TS- 130 W - E12
(東西記号) (通し番号) (付帯記号) (口金型式)


品番	TS-100-E10 (旧品番:ES-T235)		
 E10 豆ソケット台付			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		




品番	TS-101-E10 (旧品番:ES-T238-E10)		
 E10 豆ソケット			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		



品番	TS-103-E10 (TS-102-E10 代替品)		
 E10 R/G ソケット			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		




品番	TS-130W-E12 TS-130K-E12 (旧品番:ES-T237)		
 TS-130W-E12 TS-130K-E12 在庫限り E12 PSE 中ソケット			
定格	1A250V	入数	50個
外郭	PP (ポリプロピレン)		




(使用電球10W以下)


品番	TS-132-E12 (旧品番:ES-T238-E12)		
 E12 中ソケット			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		



品番	TS-133-E12 (旧品番:ES-T236)		
 E12 ソケット台付			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		




品番	TS-137-E12 (旧品番:ES-T269)		
 在庫限り E12 台付レセップ			
定格	1A300V	入数	25個
外郭	磁器		




付属:絶縁ファイバー

品番	TS-138-E12 (旧品番:ES-T239)		
 E12 豆レセップ			
定格	1A300V	入数	25個
外郭	磁器		




ランプソケット 口金 E12/E17


品番	TS-142W-E12 TS-142K-E12		
 E12 ソケット			
定格	1A250V	入数	—
外郭	PP (ポリプロピレン)		




品番	TS-161W-E17 TS-161K-E17 (旧品番:ES-T250-E17)		
 E17 耳付レセップ			
定格	3A300V	入数	25個
外郭	磁器		




品番	TS-162W-E17 TS-162K-E17 (旧品番:ES-T250コード付)		
 E17 耳付レセップコード付			
定格	3A300V	入数	10個
外郭	磁器		




品番	TS-163-E17 (旧品番:ES-T260N)		
 E17 台付レセップ			
定格	3A300V	入数	25個
外郭	磁器		



品番	TS-168-E17 (旧品番:ES-T271)		
 E17 丸形レセップ			
定格	3A300V	入数	10個
外郭	磁器		



品番	TS-165-E17 (旧品番:ES-T248-E17)		
 E17 ベークソケット			
定格	1A250V	入数	100個
外郭	PF (フェノール)		



品番	TS-166-E17 (旧品番:ES-T266)		
 E17 筒形ソケット			
定格	3A300V	入数	50個
外郭	磁器		

