






ハロゲンソケット 口金 EZ10/E11


品番	TS-603-EZ10 TS-603S-EZ10 (TS-600(S)-EZ10 代替品)			
	TS-603-EZ10	TS-603S-EZ10		
				
定格	7A30V	入数	—	
外郭	磁器			


品番	TS-604-EZ10 TS-604S-EZ10 (TS-601(S)-EZ10 代替品)			
	TS-604-EZ10	TS-604S-EZ10		
				
定格	7A30V	入数	—	
外郭	磁器			


品番	TS-605S-EZ10 (TS-602S-EZ10 代替品)			
	TS-605S-EZ10			
				
定格	7A50V	入数	—	
外郭	セラミック			

品番	TS-620-E11 TS-620S-E11 (旧品番: E-11F,FS)			
	TS-620-E11	TS-620S-E11		
				
定格	5A125V	入数	—	
外郭	セラミック			

品番	TS-621-E11 TS-621S-E11 (旧品番: E-11G,GS)			
	TS-621-E11	TS-621S-E11		
				
定格	5A125V	入数	—	
外郭	セラミック			

品番	TS-628-E11 TS-628S-E11			
	TS-628-E11	TS-628S-E11		
				
定格	7A300V	入数	—	
外郭	磁器			

品番	TS-624-E11 TS-624S-E11			
	TS-624-E11	TS-624S-E11		
				
定格	7A300V	入数	—	
外郭	磁器			

品番	TS-625S-E11 (TS-622S-E11 代替品)			
	TS-625S-E11			
				
定格	7A125V	入数	—	
外郭	セラミック			