



ランプソケット 口金 E10/E12

ソケット品番表示 について (例) $\frac{\text{TS-}}{\text{(東西記号)}} \frac{130}{\text{(通し番号)}} \frac{\text{W}}{\text{(付帯記号)}} - \frac{\text{E12}}{\text{(口金型式)}}$


品番	TS-100-E10		
	(旧品番 : ES-T235)		
 E10 豆ソケット台付			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		






品番	TS-101-E10		
	(旧品番 :ES-T238-E10)		
			
E10 豆ソケット			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		

	$\phi 15$
23	
65	$\phi 13$




品番		TS-103-E10	
		(TS-102-E10 代替品)	
			
E10 RG ソケット			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		

	$\phi 15$
23	
	$\phi 13$
230	
10	






品番		TS-132-E12	
		(旧品番:ES-T238-E12)	
			
E12 中ソケット			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		

$\phi 17.5$
23.5
$\phi 15$
70



品番	TS-133-E12		
	(旧品番:ES-T236)		
			
E12 ソケット台付			
定格	48V 未満	入数	50個
外郭	PP (ポリプロピレン)		



品番	TS-138-E12		
	(旧品番:ES-T249)		
			
E12 豆レセップ			
定格	1A300V	入数	25個
外郭	磁器		